

Temperaturverlauf in Bauteil

U-Wert ($\text{W/m}^2\text{K}$) = $1/(R_{si}+R_1+R_2+R_3+R_4+R_{se})$



